DB AIR
DOUBLE BARREL



Tuning DBAIR Volume

Volume Inserts may be added to increase the shock air spring progression

1. Remove air valve cap.
2. Release all air pressure.
3. Remove small retaining o-ring.
4. Place shock in a soft jaw vice with the air can on top.
5. Using rubber strap wrench for grip; slide air can up and off the shock.
6. Install volume insert around inner air can.
7. Inspect both air can o-rings and apply grease. Replace if necessary.
8. Re-install air can.
9. Install retaining o-ring. Rotate air can to desired orientation.
10. Inflate shock and check for proper air sealing.



