| PART # | DESCRIPTION | PART INCLUDED |
|---|---|---|
| 8022802 | AXLE,VAULT,FRONT,516 GOLD AM | I |
| 8022803 | BEARING 18X30 CN AM | H |
| 8022807 | SEAL KIT VAULT FRONT 516 AM | G,G |
| 8022805 | ENDCAP SET VAULT F 516 12x100 AM | A,B |
| 8022806 | ENDCAP SET VAULT F 516 15x100 AM | C,D |
| 8022804 | ENDCAP SET VAULT F 516 9x100QR AM | E,F |
| D60185 | BEARING,DRIFT,KIT,VAULT,F+R | NOT SHOWN |

EASTON
VAULT 516

NOTES

1. See eastoncycling.com for service and repair instructional videos
2. Remove end caps by hand, if tight try using a rubber glove or blind bearing puller tool
3. Always install rotor side bearing first
4. Longer end cap installs on rotor side
5. Lube outside facing bearing seals and end cap seals with light grease

