instruction manual

FIFTY YEARS OF SUSPENSION INNOVATION
50
SINCE 1949

BAM
BOMBER AEROSPACE MATERIAL

ORIGINAL
Open Bath
DESIGN

QR20
Z.3

bomber

MARZOCCHI SINCE 1949 MARZOCCHI SINCE 1949 MARZOCCHI SINCE 1949

GENERAL SPECIFICATIONS

- This fork is specifically designed for Downhill use. It is damped by two sealed hydraulic cartridges and sprung by a mechanical coil spring system.
- Sliders feature a special wheel axle mount shifted to the front to accommodate quick release Ø20 hubs.

NOTE: These instructions cover the special parts specific to this model. For further information, please read the attached instructions relevant to the “Z3” model (code 900488).

IMPORTANT: fixing the front wheel properly as specified in the instructions given below is essential for the proper operation of this fork and all related devices, and therefore for safe riding. You are advised to follow these instructions closely.

FRONT WHEEL ASSEMBLY

Slacken the lock nut of the quick release lever so the hub will fit between the fork sliders.
Make sure the quick release bushings (1) are centered to the recesses in the sliders.
Lock the quick release lever (2) and make sure the bushings (1) are properly seated in the sliders.

NOTE: These sliders are specifically designed to fit this type of hub. Do not use any hub design other than that specified here, as this would not ensure proper fastening of the wheel and may lead to breakdown of the assembly components.

FIG. 1

