EASTON

# VAULT 525

| PART # | DESCRIPTION | PART INCLUDED |
|---|---|---|
| 8022797 | AXLE,VAULT,REAR,525 GOLD AM | C |
| 8022798 | BEARING 6902 CM AM | B |
| 8022793 | CASS BODY VAULT CAMPY 60T AM | M,N,D,S |
| 8022792 | CASS BODY VAULT SHI 11SPD ROAD 60T AM | H,I,D,Q |
| 8022970 | CASS BODY VAULT XDR 60T AM | J,K,D,R |
| 8022796 | ENDCAP SET VAULT 525 R 10x135QR AM | P,Q,R,(S) |
| 8022795 | ENDCAP SET VAULT 525 R 12x142 AM | A,I,K,(N) |
| 8022801 | PAWL & SPRING KIT VAULT AM | 3xE, 3xF |
| 8022800 | SEAL VAULT ROAD CASSETTE BODY BLACK AM | G |
| 8022827 | SPACER VAULT CASSETTE  BODY SILVER AM | D |
| D60185 | BEARING,DRIFT,KIT,VAULT,F+R | NOT SHOWN |

## NOTES

1. See eastoncycling.com for service and repair instructional videos
2. Remove end caps by hand, if tight try using a rubber glove or blind bearing puller tool
3. Always install drive side bearing first
4. Longer end cap installs on rotor side
5. Lube with light grease:
   - I. Outside facing bearing seals
   - II. OD bearing race where end cap seal contacts
   - III. Drive ring
6. Lube with light oil:
   - I. Pawls
   - II. Cassette body seal
7. Lube with waterproof grease:
   - I. Cassette / cassette body stop interface
   - II. Outside face of XDR driver body outer bearing
   - III. Campagnolo cassette body outer bearing

