EASTON

X5 CL REAR

PART #	DESCRIPTION	PART INCLUDED
8022783	AXLE X5CL REAR 12X142/10X135QR	G
8011340	BEARING 6802 STD AM (CASSETTE BODY)	NOT SHOWN
2031688	BEARING 6903 MTN HYBRID	B
8022786	CASSETTE BODY X5 11SPD RD	C
8022454	CASSETTE BODY X5 SRAM 11 XD	NOT SHOWN
8023166	CASSETTE BODY, X5, XDR, AM	D
8022785	ENDCAP X5CL REAR 10x135 QR PAIR	F,H
8022784	ENDCAP X5CL REAR 12x142 PAIR	A,E

NOTES

1. Remove non drive-side end cap by hand, if tight try using a rubber glove or blind bearing puller tool
2. Remove drive-side end cap using 17mm cone wrench and pin (or QR axle) through holes at non drive-side of axle
   Note: tighten/loosen directions are based on left-hand thread
3. Always install drive-side bearing first
3. Longer end cap installs on rotor side
4. Lube with light grease:
   - Outside facing bearing seals
   - Drive ring
5. Lube with light oil:
   - Pawls
   - Cassette body seal
6. Lube with waterproof grease:
   - Cassette / cassette body stop interface

